



MEH-P5100R,P5150 BLOCK DIAGRAM AND SCHEMATIC DIAGRAM BLOCK DIAGRAM(MEH-P5100R/EW)

A TUNER AMP UNIT



C PU UNIT


D MD UNIT



F SW2 PCB

E SW1 PCB


www.electronicrepair.net



C KEYBOARD UNIT

BLOCK DIAGRAM(MEH-P5150/ES)

A TUNER AMP UNIT




A

B

C PU UNIT

D MD UNIT




C

D


SW2 PCB

E SW1 PCB




FM/AM TUNER UNIT(MEH-P5100R/EW)

www.electronicrepair.net



B

A



B

C

D



FM/AM TUNER UNIT(MEH-P5150/ES)

A

B


C

D

www.electronicrepair.net

A

B FM/AM TUNER UNIT



B

1


2

3


4

1ST IF (FM/AM 10.7MHz)

www.electronicrepair.net



D-b



A
B
C
D

www.electronicrepair.net

D MD UNIT




A

B


C

D


D-a D-b



FOCUS SERVO LINE
 TRACKING SERVO LINE
 CARRIAGE SERVO LINE
 SPINDLE SERVO LINE



D-a



www.electronicrepair.net

D-a D-b

D-a

A B C D


5

6

7

8

9



D-a D-b

www.electronicrepair.net

A

B

C

D