




## OVERALL CONNECTION DIAGRAM(GUIDE PAGE)

Note: When ordering service parts, be sure to refer to "EXPLODED VIEW S AND PARTS LIST" or "ELECTRICAL PARTS LIST".



[www.electronicsrepair.net](http://www.electronicsrepair.net)







[www.electronicsrepair.net](http://www.electronicsrepair.net)

A-a

A



[www.electronicsrepair.net](http://www.electronicsrepair.net)



**A-a**

www.electronicsrepair.net

A-b

1


2

3

4


# A MOTHER UNIT

CN301



# POWER AMP

CN901




A-a A-b

A

B

C

D




A-b

www.electronicsrepair.net

A-a A-b

## TUNER UNIT

**B**

1


2

3

4

# www.electronicsrepair.net

A



PA4024A

C2

B

B


C

D

## KEYBOARD UNIT


Button Illumination  
Switch Circuit

\*1 : CL19UBX



## C KEYBOARD UNIT

Key Matrix Circuit




CN957

A CN953

CN954

F CN1051




C

1

2

3

4

**A**

CN952


**C**

EQ PCB

A

**D** EQ PCB

CN201



B

**A** CN301**B****C****D**


**COMPOUND UNIT**  
 Consists of  
**EQ PCB**  
**CONNECTOR PCB**  
**VF SUB PCB**

**D**

# www.electronicsrepair.net


A

## Fix EQ Circuit



## Aut level Control Circuit

B



## Auto level Control Circuit

C


Analog Switch  
for Dual Play

	FH-2077ZF	FH-2177ZF
IC268	R01	R022
IC270	R018	R027
IC288	-	2R7K
IC290	OR0	-

D

D

## CONNECTOR PCB




**COMPOUND UNIT**  
Consists of  
EQ PCB  
CONNECTOR PCB  
VF SUB PCB



VF SUB PCB

www.electronicsrepair.net

A



<b>COMPOUND UNIT</b>
Consists of
EQ PCB
CONNECTOR PCB
VF SUB PCB

B

C

D

**F**

1



2

3

4

## CD MECHANISM MODULE


G-a

SERVICE PICKUP UNIT  
(CX1230)

G

H

## G-b



A

B


C

D


## G

G-a G-b

SERVICE PICKUP UNIT  
(CXX1230)      G CONTROL UNIT



G-a



SWITCHES:  
CONTROL UNIT  
S802 : HOME SWITCH ..... ON-OFF  
S802 : HOME SWITCH ..... ON-OFF  
The underlined indicates the switch position.

**G-a**


A

B

C


D

G-a G-b



G-b

# www.electronicsrepair.net



G-b