

MD Display Block (CX-BM1091/3091/6091F)



The following symbols are shown on the schematic diagram.


| | |
|----|----|
| 8V | 8V |
| 6V | 6V |
| 5V | 5V |

CX-BM1091F / CX-BM3091F / CX-BM6091F



MD Display Block (CX-BM8191F)


E-9023



CX-BM8191F

SCHEMATIC DIAGRAM -2

Main Block



MD Servo Block

